



Thermopatch
Since 1934

Impressio

Material: Four 16.5" x 19.68" Heat dispersing silicone foam sheets per package

Application

Thermopatch developed Impressio to prevent leaving behind shiny platen imprints after heat sealing on delicate materials.

To achieve this, you need to place the Impressio over the exposed material and around the product you wish to heat seal.

Directions for use:

You can apply the foam in several ways:

- You can apply Impressio as a cut-out mask for easy positioning of heat seal products on the same spot on multiple items. Any mask can be made to size and a collection of masks can be made to fit any need for recurring heat seal jobs.
- Also strips or any other form can be made in different sizes, which will cover up the material where necessary, leaving the exact spot open where heat sealing is planned.

Maintain an extra 3/16th of an inch around the carrier of the transfer, emblem or label to ensure even pressure on the product.



Do not cover the whole item like this!

Use as a cut-out mask

Or cut into strips

thermopatch.com